

ACCESSORY KIT INSTALLATION INSTRUCTIONS

PROPANE CONVERSION – 1NP0680

FOR USE WITH ALL MODULATING FURNACE MODELS WITH WHITE RODGERS 36E27 GAS VALVE

▲ WARNING

This conversion kit is to be installed by a qualified service agency in accordance with these instructions and all applicable codes and requirements of the authority having jurisdiction. If the information in these instructions is not followed exactly, a fire, an explosion or production of carbon monoxide may result causing property damage, personal injury or loss of life. The qualified service agency is responsible for the proper installation of this kit. The installation is not proper and complete until the operation of the converted appliance is checked as specified in these instructions supplied with the kit.

▲ CAUTION

The conversion of new certified central heating gas appliances must conform to directions outlined in this instruction. Installation must be made in accordance with American National Standard National Fuel Gas Code, ANSI Z223.1-latest edition, unless superseded by local codes. For Canadian installations, the conversion shall be carried out in accordance with the requirements of the Provincial authorities having jurisdiction and in accordance with the CAN1-B149.1 and .2 installation codes. The manufacturer accepts no responsibility for malfunctions due to improper conversions

▲ CAUTION

Lo-NOx furnaces requiring propane (LP) gas must have the NOx screens removed prior to operation. Failure to do so may result in operational problems and/or reduced heat exchanger life. Follow the instructions below for removal of the NOx screens.

GENERAL

This kit is intended for the conversion of new equipment only, from natural gas to propane gas operation.

This instruction covers the conversion of this unit when it is equipped with a White-Rodgers modulating 36E27 gas valve. The installation instruction supplied with the unit is to be used for all other aspects of the installation.

NOTICE

The original equipment gas valve on the furnace is not capable of being adjusted so as to operate on LP gas pressures. **The new gas valve in this kit must be used.**

This kit cannot be used to convert furnaces built **after August 2009** which have the White-Rodgers 36J27 gas valve. These units must use the S1-1NP0681 LP Kit.

IMPORTANT

These instructions are for the use of qualified individuals specially trained, experienced and certified in the installation of this type of equipment and related systems components. Installation and service personnel are required by some states to be licensed. Persons not qualified shall not install this equipment nor interpret these instructions.

▲ WARNING

Improper installation, adjustment, service or maintenance can cause injury or property damage; therefore, only a qualified installer or qualified service personnel should perform this conversion.

▲ WARNING

An overpressure protection device, such as a pressure regulator, which conforms to the National Fuel Gas code, ANSI Z223.1 (U.S.) or CAN-B149.1 or.2 (Canada) and acts to limit the downstream pressure to value that does not exceed 0.5 PSI (14" w.c.), must be installed in the gas piping system upstream of the furnace. Failure to do so may result in a fire or explosion or cause damage to the furnace or some of its components.

CONTENTS OF KIT

| Description | Part Number | Qty |
|---------------------------------|-------------|-----|
| Gas Line Pressure Switch | 17471 | 1 |
| Tapped Gas Pipe Nipple | 18095 | 1 |
| Modulating Gas Valve (Red Knob) | 167246 | 1 |
| Kit Installation Instruction | 247589 | 1 |
| Main Burner Orifices #55 | 18081 | 6 |
| Wire Harness | 20461 | 1 |
| Label, Conversion Rating Plate | 255649 | 1 |
| Label, LP Conversion Kit | 255424 | 1 |
| Label, Conversion Kit 90% | 255812 | 1 |

SAFETY



This is a safety alert symbol. When you see this symbol on labels or in manuals, be alert to the potential for personal injury.

Understand and pay particular attention to the signal words **DANGER**, **WARNING**, or **CAUTION**.

DANGER indicates an imminently hazardous situation, which, if not avoided, **will result in death or serious injury**.

WARNING indicates a potentially hazardous situation, which, if not avoided, **could result in death or serious injury**.

CAUTION indicates a potentially hazardous situation, which, if not avoided **may result in minor or moderate injury**. It is also used to alert against unsafe practices and hazards involving only property damage.

FURNACE CONVERSION

CAUTION

The gas supply shall be shut off prior to disconnecting the electrical power, before proceeding with the conversion.

1. Remove the upper access door.
2. Carefully remove the wires from the gas valve and note their location so they may be properly replaced. Remove the screws that hold the manifold to the manifold brackets and slide the manifold off the burners.
3. On 80% Low-NOx models, remove NOx screens using instructions in separate section below.
4. Remove the natural gas valve from the manifold.
5. Install the LP gas valve from this kit, making sure that it is tight and in approximately the same position as the old valve.
6. Remove the main burner orifices from the manifold and retain for future use.
7. Install the propane main burner orifices in the manifold and tighten them. After installing a propane orifice in each location, any leftover orifices may be discarded. If a stainless steel burner kit was purchased, refer to the kit instructions for the burner change out.
8. Reinstall the manifold in the assembly by reversing the removal process.
9. Reconnect the wires to the proper terminals on the gas valve.

10. Install the tapped gas pipe nipple (supplied with kit) into inlet fitting of gas valve. Ensure that the 1/8 inch tapped hole in the gas pipe nipple is located in the horizontal position.




FIGURE 1: Tapped Gas Pipe Nipple

11. Install (thread) the gas line pressure switch (supplied with kit) into the 1/8 NPT tapped hole in nipple applying pipe dope to the switch fitting prior to installation. Tighten the switch making sure the connection does not leak.

NOTICE

The gas line pressure switch will cause the furnace to lock out if the gas supply pressure drops below 6" w.c. The ignition control will display a fault code 7 and will reset after one hour.

12. Disconnect the purple wire from the flame sensor.
13. Using the appropriate wire harness (supplied with kit) connect the purple wire from the flame sensor into the insulated male connector; connect the two 1/4" insulated terminals to the pressure switch; and connect the remaining insulated terminal to the flame sensor.
14. Install the propane gas conversion label as described in the LABELS section of this instruction.
15. Refer to the unit installation instructions to complete the installation before continuing with these procedures.

IMPORTANT

The barbed connector on the gas valve labeled "VENT" (see Figure 1) should be used only with furnace models having a closed burner box. For furnaces without a closed burner box, the barbed connector must be left open.

**NOx SCREEN REMOVAL
(LOW-NOx 80% MODELS ONLY)**

1. Remove entire burner assembly.
2. Remove and discard NOx screens from heat exchanger tubes.
3. Reinstall burner assembly.

CALCULATING THE FURNACE INPUT (PROPANE GAS)

NOTICE

Burner orifices are sized to provide the proper input rate using propane gas with a heating value of 2500 BTU/Ft³. If the heating value of your gas is significantly different, it may be necessary to replace the orifices with different size orifices. Follow the procedure below to calculate the furnace input.

1. Turn off all gas appliances connected to the gas meter.
2. Start the furnace.
3. Use a stop watch to measure the time it takes for the furnace to burn 1 cubic ft. of gas.
4. Calculate the furnace input by using one of the following equations.

Use the following formula to calculate the furnace input.

For propane (LP) gas multiply the heat content of the gas BTU/SCF or Default 2500 BTU/SCF (93.13 MJ/m³), times 1 cubic ft. (0.028 m) of gas measured at the gas meter, times a barometric pressure and temperature correction factor of 0.960; times 3600, then divided by the time (In seconds) it took to measure 1 cubic ft. (0.028 m) of gas from the gas meter.

The formula for US input calculation using a cubic foot gas meter:

| | | |
|--|---|-----------|
| $\frac{\text{BTU/ft}^3 \times 1 \text{ cu.ft.} \times 0.960 \times 3600}{\text{Seconds it took to measure the 1 cu.ft. of gas}}$ | = | BTU/H |
| PROPANE (LP) GAS INPUT CALCULATION EXAMPLE: | | |
| $\frac{2500 \times 1 \times 0.960 \times 3600}{108}$ | = | 80,000.00 |
| Propane Gas | | |
| BTU/SCF 2500 | | |

DO NOT ADJUST the manifold pressure regulator if the actual input is equal to or within 8% less than the furnace input specified on the rating plate or if the furnace rise is above the specified rise range on the rating plate.

If the actual input is significantly higher than the furnace input specified on the rating plate then replace the gas orifices with the gas orifices of the proper size for the type of gas you are using.

TABLE 1:Inlet Gas Pressure Range

| INLET GAS PRESSURE RANGE | |
|--------------------------|-----------------------|
| Propane (LP) | |
| Minimum | 8.0" w.c. (1.99 kPa) |
| Maximum | 13.0" w.c. (3.24 kPa) |

IMPORTANT

The inlet gas pressure operating range table specifies what the minimum and maximum gas line pressures must be for the furnace to operate safely.

The gas line pressure **MUST BE**

- 11" w.c. (2.74 kPa) for Propane (LP) Gas

in order to obtain the BTU input specified on the rating plate and/or the nominal manifold pressure specified in these instructions and on the rating plate.

ADJUSTMENT OF MANIFOLD GAS PRESSURE

Follow the appropriate section in the instructions below. Refer to Figure 1 for a drawing of the locations of the pressure ports on the gas valve.

Turn gas off at the ball valve or gas cock on gas supply line before the gas valve. Find the pressure ports on the gas valve marked OUT P and IN P.

1. The manifold pressure must be taken at the port marked OUT P.
2. The inlet gas line pressure must be taken at the port marked IN P.
3. Using a 3/16" allen wrench, remove the plugs from the inlet and outlet pressure ports. Connect a 1/8" UPT barbed hose fitting to each pressure port.

IMPORTANT

For models **without** a sealed burner box, connect the manometer hose to the barbed hose fitting. For models **with** a sealed burner box, connect the manometer as described in the section below.

For models without a sealed burner box, continue to Step 9.

For models with a sealed burner box, read the inlet gas pressure using the method below.

4. Disconnect the pressure reference hose from the right side of the burner box. Using a tee fitting and a short piece of hose, connect the negative side of the manometer to the burner box as described below.
5. Remove one end the 5/16" (7.94 mm) ID flexible tubing over the pressure port on the burner box.
6. Insert the end of the 5/16" (7.94 mm) tubing, that has the 1/8" (3.175 mm) adapter at the end of the tube, in to the 1/8" (3.175 mm) tee.
7. Connect the 1/8" (3.175 mm) tee to the burner box adapter and to the negative side of a U-tube manometer or digital pressure measuring equipment with 2 – 1/8" (3.175 mm) tubes.
8. Use the 5/16" (7.94 mm x 1/8" (3.175 mm) reducing coupling and a 4" (101.6 mm) piece of 1/8" (3.175 mm) tubing to connect the positive side of the manometer to the gas valve pressure reference port.

IMPORTANT

The cap for the pressure regulator must be removed entirely to gain access to the adjustment screw. Loosening or tightening the cap does not adjust the flow of gas.

- Refer to Figure 1 for location of pressure regulator adjustment cap and adjustment screws on main gas valve.
- Turn gas and electrical supplies on and follow the operating instructions to place the unit back in operation.
- Adjust manifold pressure by adjusting gas valve regulator screw for the appropriate gas per the following:

TABLE 2:Nominal Manifold Pressure

| Nominal Manifold Pressure | |
|---------------------------|-----------------------|
| Propane (LP) Gas (Max) | 10.0" w.c. (2.49 kPa) |
| Propane (LP) Gas (Min) | 1.6" w.c. (0.40 kPa) |




FIGURE 2: Gas Valve

IMPORTANT

If gas valve regulator is turned in (clockwise), manifold pressure is increased. If screw is turned out (counterclockwise), manifold pressure will decrease.

- After the manifold pressure has been adjusted, re-calculate the furnace input to make sure you have not exceeded the specified input on the rating plate. Refer to "CALCULATING THE FURNACE INPUT (PROPANE GAS)".

- Once the correct BTU (kW) input has been established, turn the gas valve to OFF and turn the electrical supply switch to OFF; then remove the flexible tubing and fittings from the gas valve pressure tap and the pressure reference hose from the right side of the burner box and tighten the pressure tap plug using the 3/32" (2.4 mm) Allen wrench. Replace the burner box front cover (on units so equipped) and place the pressure reference hose back on the gas valve.
- Turn the electrical and gas supplies back on, and with the burners in operation, check for gas leakage around the gas valve pressure port for leakage using an approved gas detector, a non-corrosive leak detection fluid, or other leak detection methods.

WARNING

The manifold pressure must be checked with the screw-off cap for the gas valve pressure regulator in place. If not, the manifold pressure setting could result in an over-fire condition. A high manifold pressure will cause an over-fire condition, which could cause premature heat exchanger failure. If the manifold pressure is too low, sooting and eventual clogging of the heat exchanger could occur. Be sure that gas valve regulator cap is in place and burner box to gas valve pressure reference hose is connected.

CAUTION

Be sure to relight any gas appliances that were turned off at the start of this input check.

LABELS

- Remove conversion rating plate label from the shipping box. Check the natural gas to propane box. If in Canada, check the appropriate box for respective conversion station.
- Place the conversion rating plate label 255424 as close to the rating plate as possible.
- Gas appliance conversion label, write the following:
 - Kit number, located on the outside of the kit box.
 - Stamp or write in the name of the organization making conversion, address, city, state, month, and year.
- Remove label backing and affix label adjacent to the rating plate.