



PRELIMINARY REPLACEMENT PARTS

15 & 20 Ton Outdoor Split Systems

HL-15/20*

Supersedes: Nothing

035-18557-000-A-1101

Note: This is a non-comprehensive preliminary parts lists intended for stocking purposes for first production (style A) units only. It is not intended to replace the complete, comprehensive list with subsequent style changes.

#	Part Number	Description	MODELS							
			HL-15C00ATAAA1	HL-15C00ATBAA1	HL-15C00AWAAA1	HL-15C00AWBAA1	HL-20C00ATAAA1	HL-20C00ATBAA1	HL-20C00AWAAA1	HL-20C00AWBAA1
			QUANTITY PER UNIT							
1	015-03165-004	COMPRESSOR 20T 230V (COMPR 1-2)					2	2		
2	015-03169-004	COMPRESSOR 20T 460V (COMPR 1-2)							2	2
3	015-03390-004	COMPRESSOR 30T 230V (COMPR 1-4)								
4	015-03391-004	COMPRESSOR 30T 460V (COMPR 1-4)								
5	015-03392-004	COMPRESSOR 30T 575V (COMPR 1-4)								
6	015-03394-004	COMPRESSOR 40T 230V (COMPR 1-4)								
7	015-03395-004	COMPRESSOR 40T 460V (COMPR 1-4)								
8	015-03396-004	COMPRESSOR 40T 575V (COMPR 1-4)								
9	015-03412-004	COMPRESSOR 15T 230V (COMPR 1-2)	2	2						
10	015-03416-004	COMPRESSOR 15T 460V (COMPR 1-2)			2	2				
11	015-03418-004	COMPRESSOR 25&50T 460V (COMPR 1-4)								
12	015-03419-004	COMPRESSOR 25&50T 575V (COMPR 1-4)								
13	015-03420-004	COMPRESSOR 25&50T 230V (COMPR 1-4)								
14	022-06802-000	VALVE, SERVICE 15-TON SUCTION	2	2	2	2				
15	022-06803-000	VALVE, SERVICE 15-20-TON LIQUID	2	2	2	2	2	2	2	2
16	022-09009-000	VALVE, SERVICE 20-TON SUCTION					2	2	2	2
17	024-21678-000	RELAY,CONT 24V50/60HZSPST (RY3, RY4)	2	2	2	2	2	2	2	2
18	024-23972-000	RELAY,CONT 24V50/60HZDPDT (RY1-4,FR1-2,PR1-2)								
19	024-24102-000	RELAY,CONT 24V50/60HZ3PDT (RY1, RY2)	2	2	2	2	2	2	2	2
20	024-24103-000	RELAY,CONT 24V50/60HZSPST (RY3)								
21	024-24121-001	MOTOR,FAN CONDENSER 1HP, 208/230/460 50/60HZ (FM1 -4)	2	2	2	2				
22	024-24121-002	MOTOR,FAN CONDENSER 1HP, 380/415/575 50/60HZ (FM1-4)								
23	024-24121-005	MOTOR,FAN CONDENSER 1.5 HP, 208/230/460 50/60HZ (FM1-4)					2	2	2	2
24	024-24121-009	MOTOR,FAN CONDENSER 1.5 HP, 380/415/575 50/60HZ (FM1-4)								
25	024-25844-000	CONTACTOR,ELEC, 40 AMP (M1 & M3)	2	2						
26	024-25846-000	CONTACTOR,ELEC, 50 AMP (M1 & M3)					2	2		
27	024-25848-000	CONTACTOR,ELEC, 60 AMP (M1,M2,M3,M4)								
28	024-25955-000	CONTACTOR,ELEC, 30 AMP (M1 & M3)			2	2			2	2
29	024-26051-000	CONTACTOR,ELEC, 6 AMP (M2,4,5-8)	2	2	2	2	2	2	2	2
30	024-26059-000	CIRCUIT BREAKER 60A 480V (DS1)								1
31	024-26070-000	CIRCUIT BREAKER 90A 240V (DS1)		1						
32	024-27643-000	CIRCUIT BREAKER 45A 480V (DS1)				1				
33	024-31960-000	CIRCUIT BREAKER 125A 240V (DS1)						1		
34	024-31976-000	CIRCUIT BREAKER 3.2A 250V (CB1)	1	1	1	1	1	1	1	1
35	025-13292-000	FUSE, DUAL ELEMENT,250V 60A COMPRESSOR (FU1-12)								
36	025-13991-000	FUSE HOLDER, 250V, 15A,1P (FU-9[15&20T] FU-27[15-50T])	1	1	1	1	1	1	1	1
37	025-16100-000	TERMINAL BLOCK, 10 POLE (TB2)	1	1	1	1	1	1	1	1
38	025-17407-000	FUSE HOLDER, 600V, 30A,1P (FU7-8 [15&20T],25-26[25-50T])	2	2	2	2	2	2	2	2
39	025-18094-000	LUG, GROUND (GRD LUG)	1	1	1	1	1	1	1	1
40	025-18283-000	FUSE HOLDER, 250V, 60A,3P								
41	025-19282-000	LUG, GROUND	1	1	1	1	1	1	1	1
42	025-26337-000	FUSE, 250V 40A COMPRESSOR (FU1 - 12)								
43	025-27729-000	TRANSFORMER 75VA, 380/415/575V, 24V (T1)								
44	025-27750-000	FUSE,600V 1.5A TRANSX 250 VA (FU7-8 [15&20T],25-26[25-50T])	2	2	2	2	2	2	2	2
45	025-32669-000	TRANSFORMER .25KVA 208/240/480 (T2)	1	1	1	1	1	1	1	1
46	025-32669-001	TRANSFORMER .25KVA 380/415/575 (T2)								
47	025-32675-000	COVER,SWITCH PLASTIC DISCONNECT		1		1		1		1
48	025-32697-000	CONTROL, FAN CYCLE (FC1,FC2[15&20T],PS1,PS2[25-50T])	2	2	2	2	2	2	2	2
49	025-32727-002	FUSE, 125V - 10A TRANSX (FU-9 [15&20T],FU27 [25-50T])	1	1	1	1	1	1	1	1

#	Part Number	Description	MODELS								
			HL-15C00ATAAA1	HL-15C00ATBAA1	HL-15C00AWAAA1	HL-15C00AWBAA1	HL-20C00ATAAA1	HL-20C00ATBAA1	HL-20C00AWAAA1	HL-20C00AWBAA1	
			QUANTITY PER UNIT								
50	025-33450-000	HIGH PRESS CONTROL 430/265 PSIG (HP1,HP2)	2	2	2	2	2	2	2	2	2
51	025-33451-000	LOW PRESSURE CONTROL, PRESSURE 23/38 (LP1,LP2)	2	2	2	2	2	2	2	2	2
52	025-33469-000	TRANSFORMER 75VA 208/230/460 (T1)	1	1	1	1	1	1	1	1	1
53	025-35343-000	DIN RAIL,MOUNTING CONDENSER FAN CONTACTOR									
54	025-37389-000	FUSE HOLDER COND FAN (FU1-6[15&20T],FU13-24(25-50T))	2	2	2	2	2	2	2	2	2
55	025-37390-000	FUSE,600V 5.6A, COND FAN (FU1-6[15&20T],FU13-24(25-50T))	6	6							
56	025-37392-000	FUSE,600V 2.5A, COND FAN (FU1-6[15&20T],FU13-24(25-50T))									
57	025-37393-000	FUSE,600V 3A, COND FAN (FU1-6[15&20T],FU13-24(25-50T))			6	6					
58	025-37410-000	FUSE,600V 4A COND FAN (FU1-6[15&20T],FU13-24(25-50T))								6	6
59	025-37412-000	FUSE,600V 8A COND FAN (FU1-6[15&20T],FU13-24(25-50T))						6	6		
60	025-37419-000	CONTROL, TEMP, LOW AMBIENT 40° (LAS1,LAS2)	2	2	2	2	2	2	2	2	2
61	025-37420-240	CRANK CASE HEATER 230V 15T (CCH1-4)	2	2							
62	025-37421-460	CRANK CASE HEATER 460V 15T (CCH1-4)			2	2					
63	025-37423-240	CRANK CASE HEATER 230V 20,25,30&40T (CCH1-4)					2	2			
64	025-37424-460	CRANK CASE HEATER 460V 20,25,30&40T (CCH1-4)								2	2
65	025-37425-575	CRANK CASE HEATER 575V 25,30&40T (CCH1-4)									
66	026-25568-000	CLAMP, CONDENSER FAN MOTOR MOUNT	2	2	2	2	2	2	2	2	2
67	026-31435-000	GUARD,FAN 30"					2	2	2	2	2
68	026-34562-000	GUARD,FAN 24"	2	2	2	2					
69	026-34581-000	MOUNT, CONDENSER FAN MOTOR	2	2	2	2	2	2	2	2	2
70	026-35504-000	FAN,PROP,24DIA,3BL,34DEG	2	2	2	2					
71	026-38027-000	FAN,PROP,24DIA,4BL,36DEG									
72	026-38028-000	FAN,PROP,30DIA,3BL,22DEG					2	2	2	2	2
73	026-38033-000	GUARD,COIL 26.75 X 29.88	4	4	4	4					
74	026-38034-000	GUARD,COIL 37.50 X 29.88	1	1	1	1	1	1	1	1	1
75	026-38035-000	GUARD,COIL 40.00 X 29.88									
76	026-38036-000	GUARD,COIL 32.65 X 29.88	2	2	2	2	2	2	2	2	2
77	026-38037-000	GUARD,COIL 35.75 X 29.88					4	4	4	4	4
78	026-38040-000	GUARD,COIL 40.00 X 50.50									
79	026-38041-000	GUARD,COIL 35.75 X 50.50									
80	028-12342-000	GROMMET,COMPRESSOR,DUAL 25-50-TON									
81	028-13265-000	CAP,PLUG, V-PANEL ACCESS 1 1/4" (1.25)	2	2	2	2	2	2	2	2	2
82	028-13344-000	GROMMET,RUBBER COMPRESSOR 15 - 20TON	8	8	8	8	8	8	8	8	8
83	031-01947-000	CONTROL, 2 STAGE COOL/HEAT 15 & 20-TON (RB1)	1	1	1	1	1	1	1	1	1
84	031-01948-000	CONTROL, 2 STAGE COOL/HEAT SYSTEM ONE (RB1)									
85	031-01949-000	CONTROL, 2 STAGE COOL/HEAT SYSTEM TWO (RB2)									
88	073-23180-000	POST,CORNER COND. 15-40T	4	4	4	4	4	4	4	4	4
94	073-23195-000	POST,CORNER COND. 50T									
100	073-23206-000	CONTROL BOX DOOR 25 - 50-TON									
101	073-23216-000	ROOF, COMPRESSOR / CONTROL BOX	1	1	1	1	1	1	1	1	1
112	073-24006-000	POST,SIDE 50T									
119	073-24088-000	CONTROL BOX DOOR 15 & 20-TON	1	1	1	1	1	1	1	1	1
120	073-24104-000	POST,SIDE 15-40T	4	4	4	4	4	4	4	4	4
121	073-24447-000	COVER, FRONT SIDE 25-50T									
122	073-24448-000	COVER, FRONT BOTTOM 50T									