



Source 1
Replacement Parts
 Supersedes : Nothing

DL 3 thru 6 Ton
 Standard Efficiency
 Gas / Electric and Straight
 Cooling A/C
 035-19409-002-A-0603

Note: This is a non-comprehensive parts list intended for stocking purposes for first production (style A) units *based on current production*. It is not intended to replace the comprehensive list with subsequent changes.

BRACKET,FILTER,MIDDLE	029-18446-000	1			
BRACKET,FILTER,BOTTOM	029-18447-000	1			
BRACKET,FILTER,TOP	029-18445-000	1			
RAIL,BASE	063-87534-001	2			
RAIL,END	063-87544-001	1			
RAIL,END	063-89741-000	1			
PANEL,COMPRESSOR ACCESS	063-87559-000	1			
POST,CORNER,FRONT	063-87617-000	1			
POST,CORNER,REAR	063-87618-000	1			
PANEL,BAFFLE,FILTER,LH	073-21209-000	1			
BRACKET,TOP	073-21697-000	1			
BRACKET,BASE	073-21698-000	1			
COVER,DUCT	363-87667-101	3			
COVER, BASE DUCT	363-89742-000	1			
COVER,BASE DUCT	373-03111-000	1			
PANEL,BLOWER SECTION	373-03098-100	1			
ROOF,EVAPORATOR	373-03102-102	1			
PAN,CONDENSATE,STANDARD	363-87677-000	1			
PAN,CONDENSATE	063-94795-001	1			
ELBOW,90 DEGREE,PVC	023-13649-000	1			
BUSHING,CONDUIT	025-26385-000	1			
PAN,CONDENSATE,DOWN DRAIN	363-87677-001	1			
PAN,CONDENSATE	063-94795-002	1			
ADAPTER,PVC,3/4SLP	023-16807-000	1			
BUSHING,CONDUIT	025-26385-000	1			
ROOF,CONDENSER	063-93734-000	1			

CABINET OPTIONS
Standard Cabinet
Cooling/Elec Heat

PANEL,FILTER SECTION	363-87539-000	1			
POST,CABINET	073-26149-001	1			
PANEL,DUCT	373-03097-000	1			
PANEL,ACCESS,ELECTRIC HEAT	373-03088-001	1			

Gas Heat

PANEL,FILTER SECTION	363-87539-000	1			
POST,CABINET	073-26149-001	1			
PANEL,DUCT	373-03097-000	1			
PANEL,ACCESS,GAS HEAT	073-05379-001	1			

Cooling/Elec Heat						
PANEL,FILTER ACCESS	373-20676-000	1				
POST,CABINET	073-26149-002	1				
PANEL,DUCT	373-14781-206	1				
PANEL,ACCESS,ELECTRIC HEAT	373-03088-002	1				
PLATE,LATCH	073-01920-000	2				
PLATE,LATCH	073-01931-000	7				
KNOB,TEE STUD	029-22127-000	11				
Gas Heat						
PANEL,FILTER ACCESS	373-20676-000	1				
POST,CABINET	073-26149-002	1				
PANEL,DUCT	373-14781-206	1				
PANEL,ACCESS,GAS HEAT	073-05379-002	1				
PLATE,LATCH	073-01920-000	2				
PLATE,LATCH	073-01931-000	7				
KNOB,TEE STUD	029-22127-000	11				
FILTER OPTIONS						
FILTER,AIR,1X14X25	026-10019-000	1				
FILTER,AIR,1X15X20	026-34786-000	2				
FILTER,AIR,2X14X25,PLEATED	026-38038-000	1				
FILTER,AIR,2X15X20,PLEATED	026-38039-000	2				
COMPRESSORS						
Code F - 208/230-1-60						
			3 Ton	4 Ton	5 Ton	6 Ton
COMPRESSOR,H20C373DBYA	015-02938-004	1	-	-	-	-
COMPRESSOR,H20R483DBYA	015-02793-004	-	1	-	-	-
COMPRESSOR,H20R603DBYA	015-02942-004	-	-	1	-	-
COMPRESSOR,H20R753DBYA	015-02998-004	-	-	-	-	-
GROMMET,RUBBER	028-13344-000	4	4	4	-	-
Code T - 208/230-3-60						
			3 Ton	4 Ton	5 Ton	6 Ton
COMPRESSOR,H20C373DBYA	015-02989-004	1	-	-	-	-
COMPRESSOR,H20R483DBYA	015-02992-004	-	1	-	-	-
COMPRESSOR,H20R603DBYA	015-02995-004	-	-	1	-	-
COMPRESSOR,H20R753DBYA	015-02998-004	-	-	-	-	1
GROMMET,RUBBER	028-13344-000	4	4	4	4	4
Code W - 460-3-60						
			3 Ton	4 Ton	5 Ton	6 Ton
COMPRESSOR,H20C373DBEA	015-02990-004	1	-	-	-	-

COMPRESSOR,H20R483DBEA	015-02993-004	-	1	-	-
COMPRESSOR,H20R603DBEA	015-02996-004	-	-	1	-
COMPRESSOR,H20R753DBEA	015-02999-004	-	-	-	1
GROMMET,RUBBER	028-13344-000	4	4	4	4
Code X - 575-3-60					
		3 Ton	4 Ton	5 Ton	6 Ton
COMPRESSOR,H20C373DBFA	015-02991-004	1	-	-	-
COMPRESSOR,H20R483DBFA	015-02994-004	-	1	-	-
COMPRESSOR,H20R603DBFA	015-02997-004	-	-	1	-
COMPRESSOR,H20R753DBFA	015-03100-004	-	-	-	1
GROMMET,RUBBER	028-13344-000	4	4	4	4
ELECTRICAL BOX - Cooling/Electric Heat					
Code F - 208/230-1-60					
		3 Ton	4 Ton	5 Ton	6 Ton
BOARD,CIRCUIT	031-01934-002	1	1	1	-
CIRCUIT BREAKER,3.2A,250V	024-31976-000	1	1	1	-
CONTACTOR	024-27531-000	1	1	-	-
CONTACTOR,ELEC,20AMP,1P	024-25964-000	1	1	1	-
CONTACTOR,ELEC,40 AMP	024-25837-700	-	-	1	-
CONTROL,TEMPERATURE,SPST	025-38585-000	1	1	1	-
LUG,ELECTRICAL	025-21798-000	1	1	1	-
TERMINAL BLOCK,2P,300V,20A	025-23083-000	1	1	1	-
TERMINAL,GROUNDING	025-29006-000	1	1	1	-
TRANSFORMER,.075KVA,208/230	025-25973-700	1	1	1	-
Code T - 208/230-3-60					
		3 Ton	4 Ton	5 Ton	6 Ton
BOARD,CIRCUIT	031-01934-002	1	1	1	1
CIRCUIT BREAKER,3.2A,250V	024-31976-000	1	1	1	1
CONTACTOR,ELEC,20AMP,1P	024-25964-000	1	1	1	1
CONTACTOR,ELEC,30AMP	024-25955-000	1	1	1	1
CONTROL,TEMPERATURE,SPST	025-38585-000	1	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1	1
TERMINAL BLOCK,2P,300V,20A	025-23083-000	1	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1	1
TRANSFORMER,.075KVA,208/230	025-25973-700	1	1	1	1
Code W - 460-3-60					
		3 Ton	4 Ton	5 Ton	6 Ton
BOARD,CIRCUIT	031-01934-002	1	1	1	1
CIRCUIT BREAKER	024-31976-000	1	1	1	1
CONTACTOR,ELEC,20 AMP.	024-25964-000	1	1	1	1
CONTACTOR,ELEC,30 AMP.	024-25955-000	1	1	1	1
CONTROL,TEMP,SWITCH,SPST	025-38585-000	1	1	1	1

Source 1 Products

035-19409-002-A-0603
Supercedes: Nothing

New Replacement Parts shown in **bold** face at the first printing of the parts list date coded 0303

LUG,ELECTRICAL	025-21798-000	1	1	1	1
TERMINAL BLOCK,2P,300V,20A	025-23083-000	1	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1	1
TRANSFORMER,.075KVA,460PRI	025-25974-700	1	1	1	1
Code X - 575-3-60					
		3 Ton	4 Ton	5 Ton	6 Ton
BOARD,CIRCUIT	031-01934-002	1	1	1	1
CIRCUIT BREAKER	024-31976-000	1	1	1	1
CONTACTOR,ELEC,20AMP	024-25964-000	1	1	1	1
CONTACTOR,ELEC,30 AMP	024-25955-000	1	1	1	1
CONTROL,TEMP.SPST,30F	025-35355-001	1	1	1	1
CONTROL,TEMPERATURE,SWITCH	025-38585-000	1	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1	1
RELAY,CONTROL,24V,50/60HZ,SPST	024-24103-000	1	1	1	1
TERMINAL BLOCK	025-23083-000	1	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1	1
TIME DELAY	024-26089-000	1	1	1	1
TRANSFORMER,.075KVA	025-25974-700	1	1	1	1
TRANSFORMER,750VA,240/480PRI	025-32758-000	1	1	1	1
ELECTRICAL BOX - Gas Heat Units					
Code F - 208/230-1-60 - Belt & Direct Drive					
		3 Ton	4 Ton	5 Ton	6 Ton
BOARD,CIRCUIT	031-01934-002	1	1	1	-
CIRCUIT BREAKER,3.2A,250V	024-31976-000	1	1	1	-
CONTACTOR	024-27531-000	1	1	-	-
CONTACTOR,ELECTRICAL,20AMP	024-25964-000	1	1	1	-
CONTACTOR,ELECTRICAL,40AMP	024-25837-700	-	-	1	-
CONTROL,TEMP. SWITCH,SPST,45F	025-38585-000	1	1	1	-
LUG,ELECTRICAL	025-21798-000	1	1	1	-
RELAY,CONTROL,24V50/60HZ,SPST	024-24103-000	1	1	1	-
TERMINAL BLOCK,2P,300V,20A	025-23083-000	1	1	1	-
TERMINAL,GROUNDING	025-29006-000	1	1	1	-
TIME DELAY	024-26089-000	1	1	1	-
TRANSFORMER,.075KVA,208/230	025-25973-700	1	1	1	-
Code T - 208/230-3-60 - Direct Drive					
		3 Ton	4 Ton	5 Ton	6 Ton
BOARD,CIRCUIT	031-01934-002	1	1	1	1
CIRCUIT BREAKER,3.2A,250V	024-31976-000	1	1	1	1
CONTACTOR,ELECTRICAL,20AMP,1P	024-25964-000	1	1	1	1
CONTACTOR,ELECTRICAL,30AMP	024-25955-000	1	1	1	1
CONTROL,TEMP. SWITCH,SPST	025-38585-000	1	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1	1
RELAY,CONTROL,24V50/60HZ,SPST	024-24103-000	1	1	1	1

Source 1 Products

035-19409-002-A-0603
Supercedes: Nothing

New Replacement Parts shown in **bold** face at the first printing of the parts list date coded 0303

TERMINAL BLOCK,2P,300V,20A	025-23083-000	1	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1	1
TIME DELAY	024-26089-000	1	1	1	1
TRANSFORMER,.075KVA,208/230-24	025-25973-700	1	1	1	1
Code T - 208/230-3-60 - Belt Drive					
		3 Ton	4 Ton	5 Ton	6 Ton
BOARD,CIRCUIT	031-01934-002	1	1	1	1
CIRCUIT BREAKER,3.2A,250V	024-31976-000	1	1	1	1
CONTACTOR,ELECTRICAL,20AMP,1P	024-25965-000	1	1	1	1
CONTACTOR,ELECTRICAL,30AMP	024-25955-000	1	1	1	1
CONTROL,TEMPERATURE,SPST,45F	025-38585-000	1	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1	1
RELAY,CONTROL,24V50/60HZ,SPST	024-24103-000	1	1	1	1
TERMINAL BLOCK,2P,300V,20A	025-23083-000	1	1	1	1
TERMINAL GROUNDING	025-29006-000	1	1	1	1
TIME DELAY	024-26089-000	1	1	1	1
TRANSFORMER,.075KVA,208/230-24	025-25973-700	1	1	1	1
Code W - 460-3-60 - Direct Drive					
		3 Ton	4 Ton	5 Ton	6 Ton
BOARD,CIRCUIT	031-01934-002	1	1	1	1
CIRCUIT BREAKER,3.2A,250V	024-31976-000	1	1	1	1
CONTACTOR,ELECTRICAL,20AMP,1P	024-25964-000	1	1	1	1
CONTACTOR,ELECTRICAL,30AMP	024-25955-000	1	1	1	1
CONTROL,TEMPERATURE,SPST,45F	025-38585-000	1	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1	1
RELAY,CONTROL,24V50/60HZ,SPST	024-24103-000	1	1	1	1
RELAY,CONTROL,24V50/60HZDPST	024-25910-700	1	1	1	1
TERMINAL BLOCK,2P,300V,20A	025-23083-000	1	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1	1
TIME DELAY	024-26089-000	1	1	1	1
TRANSFORMER,.075KVA,460PRI	025-25974-700	1	1	1	1
Code W - 460-3-60 - Belt Drive					
		3 Ton	4 Ton	5 Ton	6 Ton
BOARD,CIRCUIT	031-01934-002	1	1	1	1
CIRCUIT BREAKER,3.2A,250V	024-31976-000	1	1	1	1
CONTACTOR,ELECTRICAL,20AMP,1P	024-25965-000	1	1	1	1
CONTACTOR,ELECTRICAL,30AMP	024-25955-000	1	1	1	1
CONTROL,TEMP. SWITCH,SPST	025-38585-000	1	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1	1
RELAY,CONTROL,24V50/60HZ,SPST	024-24103-000	1	1	1	1
RELAY,CONTROL,24V50/60HZDPST	024-25910-700	1	1	1	1
TERMINAL BLOCK,2P,300V,20A	025-23083-000	1	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1	1
TIME DELAY	024-26089-000	1	1	1	1
TRANSFORMER,.075KVA,460PRI	025-25974-700	1	1	1	1

Source 1 Products

035-19409-002-A-0603
Supercedes: Nothing

New Replacement Parts shown in **bold** face at the first printing of the parts list date coded 0303

Code X - 575-3-60		3 Ton	4 Ton	5 Ton	6 Ton
BOARD,CIRCUIT	031-01934-002	1	1	1	1
CIRCUIT BREAKER,3.2A,250V	024-31976-000	1	1	1	1
CONTACTOR,ELEC,20AMP,2P	024-25965-000	1	1	1	1
CONTACTOR,ELECTRICAL,30AMP	024-25955-000	1	1	1	1
CONTROL,TEMP. SWITCH,SPST	025-38585-000	1	1	1	1
CONTROL,TEMPERATURE,SPST,45F	025-35355-000	1	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1	1
RELAY,CONTROL,24V50/60HZ,SPST	024-24103-000	1	1	1	1
RELAY,CONTROL,24V50/60HZDPST	024-25910-700	1	1	1	1
TERMINAL BLOCK,2P,300V,20A	025-23083-000	1	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1	1
TIME DELAY	024-26089-000	1	1	1	1
TRANSFORMER,.075KVA,460PRI	025-25974-000	1	1	1	1
TRANSFORMER,750VA,240/480	025-32758-000	1	1	1	1
BLOWER,EVAPORATOR					
Direct Drive					
Code F - 208/230-1-60V					
		3 Ton	4 Ton	5 Ton	6 Ton
MOTOR,1/2HP,230V,3 SPEED	024-24106-001	1	-	-	-
MOTOR,3/4HP,120C,2 SPEED	024-21670-001	-	1	-	-
MOTOR,1PH,230	024-21672-001	-	-	1	-
BLOWER,DIRECT DRIVE	026-25539-700	1	1	1	-
HANGER,MOTOR	026-32681-700	1	1	1	-
CAPACITOR,RUN,7.5MFD	024-20045-700	1	-	-	-
CAPACITOR,RUN,12.5MFD	024-25899-000	-	1	-	-
CAPACITOR,RUN,15.0MFD	024-25900-000	-	-	1	-
Code T - 208/230-3-60V					
		3 Ton	4 Ton	5 Ton	6 Ton
MOTOR,1/2HP,230V,3 SPEED	024-24106-001	1	-	-	-
MOTOR,3/4HP,120C,2 SPEED	024-21670-001	-	1	-	-
MOTOR,1HP,230	024-21672-001	-	-	1	-
MOTOR,1HP,230V	024-24120-005				1
BLOWER,DIRECT DRIVE,230V	026-25539-700	1	1	1	-
BLOWER,DIRECT DRIVE	026-25542-700	-	-	-	1
HANGER,MOTOR	026-32681-700	1	1	1	-
HANGER,MOTOR	026-33198-700	-	-	-	1
CAPACITOR,RUN,7.5MFD	024-20045-700	1	-	-	-
CAPACITOR,RUN,12.5MFD	024-25899-000	-	1	-	-
CAPACITOR,RUN,15.0MFD	024-25900-000	-	-	1	-
CAPACITOR,RUN,15.0MFD	024-21062-700	-	-	-	1
Code W - 460-3-60V					

Source 1 Products

035-19409-002-A-0603
Supercedes: Nothing

New Replacement Parts shown in **bold** face at the first printing of the parts list date coded 0303

		3 Ton	4 Ton	5 Ton	6 Ton
MOTOR,1/2HP,460V,3 SPEED	024-24107-001	1	-	-	-
MOTOR,3/4HP,460V	024-21671-002	-	1	-	-
MOTOR,1HP,460V,3 SPEED	024-25000-002	-	-	1	-
MOTOR,1HP,460V,3 SPEED	024-24120-004	-	-	-	1
BLOWER,DIRECT DRIVE	026-25539-700	1	1	1	-
BLOWER,DIRECT DRIVE	026-25542-700	-	-	-	1
HANGER,MOTOR	026-32681-000	1	1	1	-
HANGER,MOTOR	026-33198-700	-	-	-	1
CAPACITOR,RUN,7.5MFD	024-20045-700	1	-	-	-
CAPACITOR,RUN,12.5MFD	024-25899-000	-	1	-	-
CAPACITOR,RUN,25.0MFD	024-23181-700	-	-	1	-
CAPACITOR,RUN,20.0MFD	024-21062-700	-	-	-	1
Code X - 575-3-60					
		3 Ton	4 Ton	5 Ton	6 Ton
MOTOR,1/2HP,460V,3 SPEED	024-24107-001	1	-	-	-
MOTOR,3/4HP,460V	024-21671-002	-	1	-	-
MOTOR,1HP,460V,3 SPEED	024-25000-002	-	-	1	-
MOTOR,1HP,460V,3 SPEED	024-24120-004	-	-	-	1
BLOWER,DIRECT DRIVE	026-25539-700	1	1	1	-
BLOWER,DIRECT DRIVE	026-25542-700	-	-	-	1
HANGER,MOTOR	026-32681-000	1	1	1	-
HANGER,MOTOR	026-33198-700	-	-	-	1
CAPACITOR,RUN,7.5MFD	024-20045-700	1	-	-	-
CAPACITOR,RUN,12.5MFD	024-25899-000	-	1	-	-
CAPACITOR,RUN,25.0MFD	024-23181-700	-	-	1	-
CAPACITOR,RUN,20.0MFD	024-21062-700	-	-	-	1
Belt Drive Code F - 208/230-1-60					
		3 Ton	4 Ton	5 Ton	6 Ton
MOTOR,1.5HP,115/230,1PH	024-25868-700	1	1	1	-
BLOWER,BELT DRIVE,12X10	026-25539-701	1	1	1	-
SHAFT,BLOWER,12"/15"WHEEL	001-07115-000	1	1	1	-
BEARING,BALL,PILLOW BLOCK	029-20424-700	2	2	2	-
SHEAVE,VARIABLE,1 GRV.,.625BORE	028-12361-700	1	1	1	-
SHEAVE,FIXED,1GRV.,1.000BORE	028-12383-700	1	1	1	-
BELT,V,A36	028-09573-700	1	1	-	-
BELT,V,A35	028-09572-700	-	-	1	-
CAPACITOR,RUN,25.0MFD	024-23181-700	1	1	1	-
KEY,STL,1/4Sqx2.000Lg.	001-07110-005	1	1	1	-
KEY,STL,1/4Sqx4.000Lg.	001-07110-702	1	1	1	-
BRACKET,BEARING SUPPORT	073-12442-700	2	2	2	-
BRACKET,MOTOR PIVOT	073-12444-700	1	1	1	-
BRACKET,MOTOR ADJUSTMENT	073-15128-000	1	1	1	-

Code T - 208/230-3-60					
		3 Ton	4 Ton	5 Ton	6 Ton
MOTOR,BLOWER,1.5HP,208/460	024-19623-718	1	1	1	1
BLOWER,BELT DRIVE,12x10	026-25539-701	1	1	1	-
BLOWER,BELT DRIVE,12x11	026-25542-001	-	-	-	1
SHAFT,BLOWER,12"/15"	001-07115-000	1	1	1	1
BEARING,BALL,PILLOW BLOCK	029-20424-700	2	2	2	2
SHEAVE,VARIABLE,1GRV,.878BORE	028-12385-700	1	1	1	-
SHEAVE,VARIABLE,1GRV,.878BORE	028-04764-700	-	-	-	1
SHEAVE,FIXED,1GRV,1.000BORE	028-12383-700	1	1	-	-
SHEAVE,FIXED,1GRV,1.000BORE	028-12363-700	-	-	1	1
BELT,V,A36	028-09573-000	1	1	-	1
BELT,V,A35	028-09572-700	-	-	1	-
KEY,STL,1/4Sqx2.000Lg	001-07110-005	1	1	1	1
KEY,STL,1/4Sqx4.000Lg	001-07110-702	1	1	1	1
BRACKET,BEARING SUPPORT	073-12442-700	2	2	2	2
BRACKET,MOTOR PIVOT	073-12444-700	1	1	1	1
BRACKET,MOTOR ADJUSTMENT	073-15128-000	1	1	1	1
Code W - 460-3-60V					
		3 Ton	4 Ton	5 Ton	6 Ton
MOTOR,BLOWER,1.5HP,208/460	024-19623-718	1	1	1	1
BLOWER,BELT DRIVE,12x10	026-25539-701	1	1	1	-
BLOWER,BELT DRIVE,12x11	026-25542-001	-	-	-	1
SHAFT,BLOWER12"/15"	001-07115-000	1	1	1	1
BEARING,BALL,PILLOW BLOCK	029-20424-700	2	2	2	2
SHEAVE,VARIABLE,1GRV,.878BORE	028-12385-700	1	1	1	-
SHEAVE,VARIABLE,1GRV,.878BORE	028-04764-700	-	-	-	1
SHEAVE,FIXED,1GRV,1.000BORE	028-12383-700	1	1	-	-
SHEAVE,FIXED,1GRV,1.000BORE	028-12363-000	-	-	1	1
BELT,V,A36	028-09573-700	1	1	-	1
BELT,V,A35	028-09572-700	-	-	1	-
KEY,STL,1/4Sqx2.000Lg	001-07110-005	1	1	1	1
KEY,STL,1/4Sqx4.000Lg	001-07110-702	1	1	1	1
BRACKET,BEARING SUPPORT	073-12442-700	2	2	2	2
BRACKET,MOTOR PIVOT	073-12444-700	1	1	1	1
BRACKET,MOTOR ADJUSTMENT	073-15128-000	1	1	1	1
Code X - 575-3-60V					
		3 Ton	4 Ton	5 Ton	6 Ton
MOTOR,BLOWER,1.5HP,575V	024-19623-707	1	1	1	1
BLOWER,BELT DRIVE,12x10	026-25539-701	1	1	1	-
BLOWER,BELT DRIVE,12x11	026-25542-001	-	-	-	1
SHAFT,BLOWER,12"/15"	001-07115-000	1	1	1	1
BEARING,BALL,PILLOW BLOCK	029-20424-700	2	2	2	2
SHEAVE,FIXED,1 GRV,.878BORE	028-12385-700	1	1	1	-
SHEAVE,FIXED,1 GRV,1.000BORE	028-12383-700	1	-	-	-
SHEAVE,FIXED,1 GRV,1.000BORE	028-12363-700	-	1	1	-

Source 1 Products

035-19409-002-A-0603

Supercedes: Nothing

New Replacement Parts shown in **bold** face at the first printing of the parts list date coded 0303

SHEAVE,VARIABLE,1 GRV,.878BORE	028-04764-700	-	-	-	1
SHEAVE,VARIABLE,FIXED,1GRV,1.000Br.	028-12363-700	-	-	-	1
BELT,V,A36	028-09573-700	1	-	-	1
BELT,V,A35	028-09572-700	-	1	1	-
KEY,STL,1/4Sqx2.000Lg	001-07110-005	1	1	1	1
KEY,STL,1/4Sqx4.000Lg	001-07110-702	1	1	1	1
BRACKET,BEARING SUPPORT	073-12442-700	2	2	2	2
BRACKET,MOTOR PIVOT	073-12444-700	1	1	1	1
BRACKET,MOTOR ADJUSTMENT	073-15128-000	1	1	1	1
Condenser Fan Motor					
208/230-1-60					
208/230-3-60					
		3 Ton	4 Ton	5 Ton	6 Ton
MOTOR,FAN,1/4HP,208/230	024-27500-000	1	1	1	-
FAN,PROP	026-25511-700	1	1	1	-
CAPACITOR,RUN,5.0/MFD	024-20043-700	1	1	1	-
HARNESS,FAN MOTOR	025-30804-000	1	1	1	-
GUARD,FAN	026-25528-700	1	1	1	-
ORIFICE,FAN	063-89756-000	-	1	-	-
CHANNEL,CONDENSER ROOF	063-93734-000	1	1	1	-
NUT,ACORN,#8-32	021-16829-000	4	4	4	-
460-3-60					
575-3-60					
		3 Ton	4 Ton	5 Ton	6 Ton
MOTOR,FAN	024-27501-000	1	1	1	1
FAN,PROP	026-25511-700	1	1	1	1
CAPACITOR,RUN,5.0/MFD	024-20043-700	1	1	1	1
HARNESS,FAN MOTOR	025-30804-000	1	1	1	1
ORIFICE,FAN	063-89756-000	-	1	-	1
NUT,ACORN,#8-32	021-16829-000	4	4	4	4
CHANNEL,CONDENSER ROOF	063-93734-000	1	1	1	1
VENTER BLOWER - See GAS HEAT					
CONDENSER COIL					
3 thru 6 Ton					
		3 Ton	4 Ton	5 Ton	6 Ton
COIL,CONDENSER	373-18960-100	1	1	-	-
COIL,CONDENSER,TECHNICOATED	373-18960-150	1	1	-	-
COIL,CONDENSER	373-18961-100	-	-	1	-
COIL,CONDENSER,TECHNICOATED	373-18961-150	-	-	1	-

COIL,CONDENSER	373-07820-100	-	-	-	1
COIL,CONDENSER,TECHNICOATED	373-07820-150	-	-	-	1
DISTRIBUTOR,3 FEED,.500ID	026-21486-000	-	-	-	1
DISTRIBUTOR,REFRIGERANT	026-23209-000	1	1	-	-
HEADER,CONNECTION	373-18960-050	1	1	-	-
HEADER,RETURN	373-18961-060	-	-	1	-
HEADER,DISCHARGE	373-18961-050	-	-	1	-
HEADER,DISCHARGE	373-07820-030	-	-	-	1
HEADER, ASSY	373-07820-050	-	-	-	1
HEADER,INTERMEDIATE	373-07820-040	-	-	-	1

EVAPORATOR COIL
Direct Drive

		3 Ton	4 Ton	5 Ton	6 Ton
COIL,EVAPORATOR	373-18951-001	1	-	-	-
COIL,EVAPORATOR	373-18652-001	-	1	-	-
COIL,EVAPORATOR	373-18953-001	-	-	1	-
COIL,EVAPORATOR	373-18954-000	-	-	-	1
VALVE,DISTRIBUTOR,6 TUBE,# 76	022-06844-107	1	-	-	-
VALVE,DISTRIBUTOR,6 TUBE,# 84	022-06844-059	-	1	-	-
VALVE,DISTRIBUTOR,7 TUBE,# 94	022-06844-035	-	-	1	-
VALVE,DISTRIBUTOR,7 TUBE,#106	022-06844-075	-	-	-	1
HEADER,ID COIL,3 TON	373-18951-030	1	-	-	-
HEADER,ID COIL,4 TON	373-18952-030	-	1	-	-
HEADER,ID COIL,5 TON	373-03059-030	-	-	1	-
HEADER,ID COIL,6 TON	373-18954-030	-	-	-	1

Belt Drive

		3 Ton	4 Ton	5 Ton	6 Ton
COIL,EVAPORATOR	373-18951-002	1	-	-	-
COIL,EVAPORATOR	373-18952-002	-	1	-	-
COIL,EVAPORATOR	373-18953-002	-	-	1	-
COIL,EVAPORATOR	373-18954-000	-	-	-	1
VALVE,DISTRIBUTOR,6 TUBE,# 80	022-06844-073	1	-	-	-
VALVE,DISTRIBUTOR,6 TUBE,# 84	022-06844-072	-	1	-	-
VALVE,DISTRIBUTOR,7 TUBE,# 94	022-06844-067	-	-	1	-
VALVE,DISTRIBUTOR,7 TUBE,#106	022-06844-075	-	-	-	1
HEADER, ID COIL 3 TON	373-18951-030	1	-	-	-
HEADER, ID COIL 4 TON	373-18952-030	-	1	-	-
HEADER ID COIL 5 TON	373-03059-030	-	-	1	-
HEADER,ID COIL,6 TON	373-18954-030	-	-	-	1
SUPPORT,COIL TOP	073-13611-000	1	-	-	-
SUPPORT,COIL TOP	073-13610-000	-	1	-	-
SUPPORT,COIL TOP	073-13612-000	-	-	1	-

PIPING

		3 Ton	4 Ton	5 Ton	6 Ton
--	--	-------	-------	-------	-------

CONTROL,PRESS,RFG380/300 O/C	025-17620-014	1	1	1	1
CONTROL,TEMP	025-27727-001	1	1	1	1
SWITCH,LOW PRESSURE	025-30249-700	1	1	1	1
FILTER,SOLID	026-35463-000	1	1	1	1
CORE,V PORT /SCHRAEDER	022-02475-700	2	2	2	2
STEM,VALVE 1/4 OD TUBE	022-08017-000	2	2	2	2
CAP SEAL 1/4 FLARE	023-10745-000	2	2	2	2

HEAT SECTION

Gas Heat

50MBH Heat Capacity - 2 Tube

Aluminized Steel Heat Exchanger

		208/230-1-60	208/230-3-60	460-3-60	575-3-60
BAFFLE,HEAT EXCHANGER	073-13498-000	2		2	
BAFFLE,AIR,4 TUBE	063-93668-003	1		1	
BOTTOM,FLUE BOX	373-02085-001	1		1	
BRACKET,BURNER	073-05908-000	1		1	
BRACKET,HEAT EXCHANGER	073-20260-000	2		2	
BRACKET,LIMIT SWITCH	073-18432-000	1		1	
BRACKET,MANIFOLD	063-93548-000	1		1	
BURNER,INSHOT	029-21121-000	2		2	
CONTROL,SPARK	025-29012-004	1		1	
CONTROL,TEMPERATURE	025-32655-000	1		1	
HEAT,EXCHANGER,2 TUBE	373-12894-702	1		1	
HOOD,RAIN FLUE	363-93686-700	1		1	
HOOD,FURNACE PANEL	073-21358-000	1		1	
IGNITER,SPARK	025-30372-000	1		1	
MANIFOLD,GAS	029-20078-000	1		1	
MOTOR,VENTER,1/3HP,208/230	024-24115-018	1		-	
MOTOR,VENTER,1/3HP,460V	024-24115-019	-		1	
ORIFICE,GAS BURNER,#42	029-20423-042	2		2	
ORIFICE,GAS BURNER,BLANK	029-20423-000	3		3	
ORIFICE,GAS,PILOT.#63	029-20422-063	1		1	
PLATE,BALANCE,5 BURNER	073-12880-005	1		1	
PLATE,ORIFICE,1.719 DIA.	063-90038-029	1		1	
PLATE,SHOOT THRU,5 TUBE	073-13687-005	1		1	
PLATE,VENT	073-05377-000	1		1	
SCREEN,1.000X2.000	026-31402-000	1		1	
SCROLL,VENT	073-05376-000	1		1	
SENSOR,FLAME	025-30802-000	1		1	
SWITCH,LIMIT	025-26392-011	1		1	
SWITCH,LIMIT,SPDT	025-31830-000	1		1	

TUBE,CARRYOVER,4/5 TUBE	073-12892-701	1	1
VALVE,GAS	025-30105-700	1	1
WHEEL,VENTER,BLOWER	026-32623-700	1	1
Stainless Steel Heat Exchanger			
		208/230-1-60	208/230-3-60
			460-3-60
			575-3-60
BAFFLE,AIR,4 TUBE	063-93668-003	1	1
BOTTOM,FLUE BOX	373-02085-702	1	1
BRACKET,BURNER	073-05908-000	1	1
BRACKET,HEAT EXCHANGER	073-20260-700	2	2
BRACKET,LIMIT SWITCH	073-18432-000	1	1
BRACKET,MANIFOLD	063-93548-000	1	1
BURNER,INSHOT	029-21121-000	2	2
CONTR OL,SPARK	025-29012-004	1	1
CONTROL,TEMPERATURE	025-32655-000	1	1
HEAT,EXCHANGER,2 TUBE,SS	373-12894-706	1	1
HOOD,RAIN FLUE,SS	026-38657-700	1	1
HOOD,FURNACE PANEL	073-21358-000	1	1
IGNITER,SPARK	025-30372-000	1	1
MANIFOLD,GAS	029-20078-000	1	1
MOTOR,VENTER,1/3HP,208/230	024-24115-018	1	-
MOTOR,VENTER,1/3HP,460V	024-24115-019	-	1
ORIFICE,GAS BURNER,#42	029-20423-042	2	2
ORIFICE,GAS BURNER,BLANK	029-20423-000	3	3
ORIFICE,GAS,PILOT.#63	029-20422-056	1	1
PLATE,BALANCE,5 BURNER	073-12880-005	1	1
PLATE,ORIFICE,1.719 DIA.	026-39254-700	1	1
PLATE,SHOOT THRU,5 TUBE	073-13687-005	1	1
PLATE,VENT,SS	026-39252-700	1	1
SCREEN,1.000X2.000	026-31402-000	1	1
SCROLL,VENT,SS	026-39251-700	1	1
SENSOR,FLAME	025-30802-000	1	1
SWITCH,LIMIT	025-26392-011	1	1
SWITCH,LIMIT,SPDT	025-31830-000	1	1
TUBE,CARRYOVER,4/5 TUBE	073-12892-701	1	1
VALVE,GAS	025-30105-700	1	1
WHEEL,VENTER,BLOWER	026-32623-700	1	1
75MBH Heat Capacity - 3 Tube Aluminized Steel Heat Exchanger			
		208/230-1-60	208/230-3-60
			460-3-60
			575-3-60

BAFFLE,HEAT EXCHANGER	073-13498-000	3	3
BAFFLE,AIR,3 TUBE	063-93668-002	1	1
BOTTOM,FLUE BOX	373-02085-001	1	1
BRACKET,BURNER	073-05908-000	1	1
BRACKET,HEAT EXCHANGER	073-20260-000	2	2
BRACKET,LIMIT SWITCH	073-18432-000	1	1
BRACKET,MANIFOLD	063-93548-000	1	1
BURNER,INSHOT	029-21121-000	3	3
CONTROL,SPARK	025-29012-004	1	1
CONTROL,TEMPERATURE	025-32655-000	1	1
HEAT,EXCHANGER,3 TUBE	373-12894-703	1	1
HOOD,RAIN FLUE	363-93686-700	1	1
HOOD,FURNACE PANEL	073-21358-000	1	1
IGNITER,SPARK	025-30372-000	1	1
MANIFOLD,GAS	029-20078-000	1	1
MOTOR,VENTER,1/3HP,208/230	024-24115-018	1	-
MOTOR,VENTER,1/3HP,460V	024-24115-019	-	1
ORIFICE,GAS BURNER,#42	029-20423-042	3	3
ORIFICE,GAS BURNER,BLANK	029-20423-000	2	2
ORIFICE,GAS,PILOT.#63	029-20422-063	1	1
PLATE,BALANCE,5 BURNER	073-12880-005	1	1
PLATE,ORIFICE,1.906 DIA.	063-90038-028	1	1
PLATE,SHOOT THRU,5 TUBE	073-13687-005	1	1
PLATE,VENT	073-05377-000	1	1
SCREEN,1.000X2.000	026-31402-000	1	1
SCROLL,VENT	073-05376-000	1	1
SENSOR,FLAME	025-30802-000	1	1
SWITCH,LIMIT	025-26392-011	1	1
SWITCH,LIMIT,SPDT	025-31830-000	1	1
TUBE,CARRYOVER,4/5 TUBE	073-12892-702	1	1
VALVE,GAS	025-30105-700	1	1
WHEEL,VENTER,BLOWER	026-32623-700	1	1

Stainless Steel Heat Exchanger

		208/230-1-60	208/230-3-60	460-3-60 575-3-60
BAFFLE,AIR,3 TUBE	063-93668-002	1		1
BOTTOM,FLUE BOX	373-02085-002	1		1
BRACKET,BURNER	073-05908-000	1		1
BRACKET,HEAT EXCHANGER	073-20260-700	2		2
BRACKET,LIMIT SWITCH	073-18432-000	1		1
BRACKET,MANIFOLD	063-93548-000	1		1
BURNER,INSHOT	029-21121-000	2		2
CONTROL,SPARK	025-29012-004	1		1
CONTROL,TEMPERATURE	025-32655-000	1		1
HEAT,EXCHANGER,3 TUBE,SS	373-12894-007	1		1

HOOD,RAIN FLUE,SS	026-38657-000	1	1
HOOD,FURNACE PANEL	073-21358-000	1	1
IGNITER,SPARK	025-30372-000	1	1
MANIFOLD,GAS	029-20078-000	1	1
MOTOR,VENTER,1/3HP,208/230	024-24115-018	1	-
MOTOR,VENTER,1/3HP,460V	024-24115-019	-	1
ORIFICE,GAS BURNER,#42	029-20423-042	3	3
ORIFICE,GAS BURNER,BLANK	029-20423-000	2	2
ORIFICE,GAS,PILOT.#63	029-20422-056	1	1
PLATE,BALANCE,5 BURNER	073-12880-005	1	1
PLATE,ORIFICE,1.906 DIA.	026-39255-000	1	1
PLATE,SHOOT THRU,5 TUBE	073-13687-005	1	1
PLATE,VENT,SS	026-39252-000	1	1
SCREEN,1.000X2.000	026-31402-000	1	1
SCROLL,VENT,SS	026-39251-000	1	1
SENSOR,FLAME	025-30802-000	1	1
SWITCH,LIMIT	025-26392-011	1	1
SWITCH,LIMIT,SPDT	025-31830-000	1	1
TUBE,CARRYOVER,4/5 TUBE	073-12892-702	1	1
VALVE,GAS	025-30105-700	1	1
WHEEL,VENTER,BLOWER	026-32623-700	1	1

100MBH Heat Capacity - 4 Tube

Aluminized Steel Heat Exchanger

		208/230-1-60	208/230-3-60	460-3-60	575-3-60
BAFFLE,HEAT EXCHANGER	073-13498-000	4		4	
BAFFLE,AIR,4 TUBE	063-93668-001	1		1	
BOTTOM,FLUE BOX	373-02085-001	1		1	
BRACKET,BURNER	073-05908-000	1		1	
BRACKET,HEAT EXCHANGER	073-20260-000	2		2	
BRACKET,LIMIT SWITCH	073-18432-000	1		1	
BRACKET,MANIFOLD	063-93548-000	1		1	
BURNER,INSHOT	029-21121-000	4		4	
CONTROL,SPARK	025-29012-004	1		1	
CONTROL,TEMPERATURE	025-32655-000	1		1	
HEAT,EXCHANGER,4 TUBE	373-12894-004	1		1	
HOOD,RAIN FLUE	363-93688-700	1		1	
HOOD,FURNACE PANEL	073-21358-000	1		1	
IGNITER,SPARK	025-30372-000	1		1	
MANIFOLD,GAS	029-20078-000	1		1	
MOTOR,VENTER,1/3HP,208/230	024-24115-018	1		-	
MOTOR,VENTER,1/3HP,460V	024-24115-019	-		1	
ORIFICE,GAS BURNER,#42	029-20423-042	4		4	

ORIFICE,GAS BURNER,BLANK	029-20423-000	1	1
ORIFICE,GAS,PILOT.#56	029-20422-056	1	1
PLATE,BALANCE,5 BURNER	073-12880-005	1	1
PLATE,ORIFICE,2.125 DIA.	063-90038-023	1	1
PLATE,SHOOT THRU,5 TUBE	073-13687-005	1	1
PLATE,VENT	073-05377-000	1	1
SCREEN,1.000X2.000	026-31402-000	1	1
SCROLL,VENT	073-05376-000	1	1
SENSOR,FLAME	025-30802-000	1	1
SWITCH,LIMIT	025-26392-011	1	1
SWITCH,LIMIT,SPDT	025-31830-000	1	1
TUBE,CARRYOVER,4/5 TUBE	073-12892-701	1	1
VALVE,GAS	025-30105-700	1	1
WHEEL,VENTER,BLOWER	026-32623-700	1	1
Stainless Steel Heat Exchanger			
		208/230-1-60	208/230-3-60
			460-3-60
			575-3-60
BAFFLE,AIR,4 TUBE	063-93668-001	1	1
BOTTOM,FLUE BOX	026-39250-000	1	1
BRACKET,BURNER	073-05908-000	1	1
BRACKET,HEAT EXCHANGER	073-20260-000	2	2
BRACKET,LIMIT SWITCH	073-18432-000	1	1
BRACKET,MANIFOLD	063-93548-000	1	1
BURNER,INSHOT	029-21121-000	4	4
CONTROL,SPARK	025-29012-004	1	1
CONTROL,TEMPERATURE	025-32655-000	1	1
HEAT EXCHANGER,4 TUBE, SS	373-12894-008	1	1
HOOD,RAIN FLUE,SS	026-38657-000	1	1
HOOD,FURNACE PANEL	073-21358-000	1	1
IGNITER,SPARK	025-30372-000	1	1
MANIFOLD,GAS	029-20078-000	1	1
MOTOR,.03HP,208/230	024-24115-018	1	0
MOTOR,.03HP,460V	024-24115-019	0	1
ORIFICE,GAS,BURNER,#42	029-20423-042	4	4
ORIFICE,GAS,BURNER,BLANK	029-20423-000	1	1
ORIFICE,GAS,PILOT,#56	029-20422-056	1	1
PLATE,BALANCE,5 BURNER	073-12880-005	1	1
PLATE,ORIFICE,2.125DIA	026-39256-000	1	1
PLATE,SHOOT THRU,5 TUBE	073-13687-005	1	1
PLATE,VENT,SS	026-39252-000	1	1
SCREEN,1.000X2.000	026-31402-000	1	1
SCROLL,VENT,SS	026-39251-000	1	1
SENSOR,FLAME	025-30802-000	1	1
SWITCH,LIMIT,145/225	025-26392-011	1	1
SWITCH,LIMIT,SPDT	025-31830-000	1	1
TUBE,CARRYOVER,4/5 TUBE	073-12892-701	1	1

VALVE,GAS	025-30105-700	1	1
WHEEL,BLOWER,4DIA,.250BORE	026-32623-700	1	1
125MBH Heat Capacity - 5 Tube			
Aluminized Steel Heat Exchanger			
		208/230-1-60	460-3-60
		208/230-3-60	575-3-60
BAFFLE, HEAT EXCHANGER	073-13498-000	5	5
BOTTOM,FLUE BOX	073-02085-001	1	1
BRACKET,MANIFOLD	063-93548-000	1	1
BRACKET,BURNER	073-05908-000	1	1
BRACKET,HEAT EXCHANGER	073-20260-000	2	2
BRACKET,LIMIT SWITCH	073-18432-000	1	1
BURNER,INSHOT	029-21121-000	5	5
CONTROL,SPARK	025-29012-004	1	1
CONTROL,TEMPERATURE	025-32655-000	1	1
HEAT EXCHANGER,5 TUBE	373-12894-705	1	1
HOOD,RAIN,FLUE	363-93686-000	1	1
HOOD,FURNACE PANEL	073-21358-000	1	1
IGNITER,SPARK	025-30372-000	1	1
MANIFOLD,GAS	029-20078-000	1	1
MOTOR,VENTER,.03HP,208/230	024-24115-018	1	0
MOTOR,VENTER,.03HP,460V	024-24115-019	0	1
ORIFICE,GAS,BURNER,#42	029-20423-042	5	5
ORIFICE,GAS,PILOT,#56	029-20422-056	1	1
PLATE,PATCH,GAS LINE	063-93525-700	1	1
PLATE,BALANCE, 5 BURNER	073-12880-005	1	1
PLATE,SHOOT THRU 5 TUBE	073-13687-005	1	1
PLATE,ORIFICE 2.250 DIA	063-90038-022	1	1
PLATE,VENT	073-05377-000	1	1
SCREEN,1.000X2.000	026-31402-000	1	1
SCROLL,VENT	073-05376-000	1	1
SENSOR,FLAME	025-30802-000	1	1
SPACER,VENT MOTOR 1/4 X	063-92626-000	4	4
SWITCH,LIMIT 145/225 60TX	025-26392-011	1	1
SWITCH,LIMIT,SPDT	025-31830-000	1	1
TUBE,CARRYOVER 4/5 TUBE	073-12892-701	1	1
VALVE,GAS	025-30105-700	1	1
WHEEL,VENTER,BLOWER	026-32623-700	1	1
Stainless Steel Heat Exchanger			
		208/230-1-60	460-3-60
		208/230-3-60	575-3-60

BAFFLE,AIR,4 TUBE	063-93668-001	1	1
BOTTOM,FLUE BOX	373-02085-002	1	1
BRACKET,BURNER	073-05908-000	1	1
BRACKET,HEAT EXCHANGER	073-20260-000	2	2
BRACKET,LIMIT SWITCH	073-18432-000	1	1
BRACKET,MANIFOLD	063-93548-000	1	1
BURNER,INSHOT	029-21121-000	5	5
CONTROL,SPARK	025-29012-004	1	1
CONTROL,TEMPERATURE	025-32655-000	1	1
HEAT EXCHANGER,5 TUBE, SS	373-12894-009	1	1
HOOD,RAIN FLUE,SS	026-38657-000	1	1
HOOD,FURNACE PANEL	073-21358-000	1	1
IGNITER,SPARK	025-30372-000	1	1
MANIFOLD,GAS	029-20078-000	1	1
MOTOR,.03HP,208/230	024-24115-018	1	0
MOTOR,.03HP,460V	024-24115-019	0	1
ORIFICE,GAS,BURNER,#42	029-20423-042	5	5
ORIFICE,GAS,PILOT,#56	029-20422-056	1	1
PLATE,BALANCE,5 BURNER	073-12880-005	1	1
PLATE,ORIFICE,2.125DIA	026-39256-000	1	1
PLATE,SHOOT THRU,5 TUBE	073-13687-005	1	1
PLATE,VENT,SS	026-39252-000	1	1
SCREEN,1.000X2.000	026-31402-000	1	1
SCROLL,VENT,SS	026-39251-000	1	1
SENSOR,FLAME	025-30802-000	1	1
SWITCH,LIMIT,145/225	025-26392-011	1	1
SWITCH,LIMIT,SPDT	025-31830-000	1	1
TUBE,CARRYOVER,4/5 TUBE	073-12892-701	1	1
VALVE,GAS	025-30105-700	1	1
WHEEL,BLOWER,4DIA,.250BORE	026-32623-700	1	1

ELECTRIC HEAT

**208/230-1-60
5KW**

		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,5.3KW,240V,3ELEM	025-26319-004	1	1	1	-
RELAY,HEAT SEQUENCER	024-19082-029	1	1	1	-
SWITCH,LIMIT	025-22273-002	1	1	1	-
FUSE,DUAL,250V,50A	025-26336-000	2	2	2	-
FUSE,DUAL250V,30A	025-04649-000	1	1	1	-
FUSEHOLDER,#19,20,250V	025-26333-000	1	1	1	-

7KW

		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,7.5KW,240V,3ELEM	025-26319-002	1	1	1	-
RELAY,HEAT SEQUENCER	024-19082-030	1	1	1	-

Source 1 Products

035-19409-002-A-0603
Supercedes: Nothing

New Replacement Parts shown in **bold** face at the first printing of the parts list date coded 0303

SWITCH,LIMIT	025-22273-002	2	2	2	-
FUSE,DUAL,250V,40A	025-26337-000	2	2	2	-
FUSE,DUAL,250V,50A	025-26336-000	2	2	2	-
FUSEHOLDER,#20,250V,30/60A	025-26340-000	1	1	1	-
10KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,10.6KW240V,3ELEM	025-26319-003	1	1	1	-
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1	-
SWITCH,LIMIT,COMB	025-22273-002	3	3	3	-
FUSE,DUAL,250V 60A	025-13292-000	2	2	2	-
FUSE,DUAL,250V 50A, .40X	025-26336-000	2	2	2	-
FUSEHOLDER,#20,250V,30/60A,4P	025-26340-000	1	1	1	-
15KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,15.9KW,240	025-26318-001	1	1	1	-
RELAY,HEAT SEQUENCER	024-19082-030	1	1	1	-
RELAY,HEAT SEQUENCER	024-19082-032	1	1	1	-
SWITCH,LIMIT,COMB	025-22273-002	3	3	3	-
FUSE,DUAL,250V 30A, 9X16X2	025-04649-000	2	2	2	-
FUSE,DUAL,250V 60A,	025-13292-000	2	2	2	-
FUSE,DUAL,250V 50A, .40X	025-26336-000	2	2	2	-
FUSEHOLDER,#19,20,20,250V	025-26341-000	1	1	1	-
20KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,21.2KW,240	025-26318-002	1	1	1	-
RELAY,HEAT SEQUENCER	024-19082-030	1	1	1	-
RELAY,HEAT SEQUENCER	024-19082-033	2	2	2	-
SWITCH,LIMIT,COMB	025-22273-001	5	5	5	-
SWITCH,LIMIT,COMB	025-22273-002	1	1	1	-
FUSE,DUAL,250V 50A	025-26336-000	2	2	2	-
FUSE,DUAL,250V 60A	025-13292-000	4	4	4	-
FUSEHOLDER,#20,250V, 60A,6P	025-26343-000	1	1	1	-
30KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,29.6KW,240	025-26318-003	-	-	1	-
RELAY,HEAT SEQUENCER	024-19082-030	-	-	1	-
RELAY,HEAT SEQUENCER	024-19082-033	-	-	2	-
SWITCH,LIMIT,COMB	025-22273-001	-	-	6	-
FUSE,DUAL,250V 60A	025-13292-000	-	-	8	-
FUSEHOLDER,#20,250V, 60A,4P	025-26355-000	-	-	2	-
208/230-3-60					

5KW		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,5.3KW,240V,3ELEM	025-26319-001	1	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3	3
7KW		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,7.5KW,240V,3ELEM	025-26319-005	1	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3	3
10KW		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,10.6KW,240V,3ELEM	025-26319-003	1	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1	1
SWITCH,LIMIT,COMB	025-22273-001	3	3	3	3
FUSE,DUAL,250V,45A,	025-08436-000	3	3	3	3
FUSE,DUAL,250V,35A,	025-15491-000	3	3	3	3
FUSEHOLDER,#20,250V,60A	025-19971-000	1	1	1	1
15KW		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,15.9KW,240	025-26318-001	1	1	1	1
RELAY,HEAT SEQUENCER	024-19082-030	1	1	1	1
RELAY,HEAT SEQUENCER	024-19082-032	1	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3	3
FUSE,DUAL,250V,50A	025-26336-000	3	3	3	3
FUSE,DUAL,250V,45A	025-08436-000	3	3	3	3
FUSEHOLDER,#20,250V,60A,3P	025-19971-000	1	1	1	1
20KW		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,21.2KW,240	025-26318-002	1	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1	1
RELAY,HEAT SEQUENCER	024-19082-034	1	1	1	1
SWITCH,LIMIT,COMB	025-22273-001	6	6	6	6
FUSE,DUAL,250V 35A	025-15491-000	6	6	6	6
FUSE,DUAL,250V,45A	025-08436-000	3	3	3	3
FUSEHOLDER,#20,250V, 60A,6P	025-26343-000	1	1	1	1
FUSEHOLDER,#20,250V, 60A,3P	025-26344-000	1	1	1	1
30KW		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,29.6KW,240	025-26318-003	-	-	1	1
RELAY,HEAT SEQUENCER	024-19082-031	-	-	1	1
RELAY,HEAT SEQUENCER	024-19082-034	-	-	1	1
SWITCH,LIMIT,COMB	025-22273-001	-	-	3	3

Source 1 Products

035-19409-002-A-0603

Supercedes: Nothing

New Replacement Parts shown in **bold** face at the first printing of the parts list date coded 0303

SWITCH,LIMIT,COMB	025-22273-003	-	-	3	3
FUSE,DUAL,250V 45A	025-08436-000	-	-	9	9
FUSEHOLDER,#20,250V, 60A,6P	025-26343-000	-	-	1	1
FUSEHOLDER,#20,250V, 60A,3P	025-26344-000	-	-	1	1
460-3-60					
7KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC, 6.8KW480V,6ELEM	025-26318-010	1	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3	3
10KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,10.0KW480V,6ELEM	025-26318-005	1	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3	3
15KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,13.6KW480V.6ELEM	025-26318-008	1	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3	3
20KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,19.5KW,480	025-26318-007	1	1	1	1
RELAY,CONT 24V50/60HZSPST	024-24103-000	1	1	1	1
CONTACTOR,ELEC,	024-24100-700	1	1	1	1
CONTACTOR,ELEC,	024-24101-700	2	2	2	2
CONTROL,TEMPERATURE	025-26339-002	1	1	1	1
30KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,28.8KW,480	025-26318-009	-	-	1	1
RELAY,CONT 24V50/60HZSPST	024-24103-000	-	-	1	1
CONTACTOR,ELEC,	024-24100-700	-	-	1	1
CONTACTOR,ELEC,	024-24101-700	-	-	2	2
CONTROL,TEMPERATURE	025-26339-001	-	-	1	1
575-3-60					
10KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,10.6KW600V,6ELEM	025-26318-004	1	1	1	1

RELAY,HEAT SEQUENCER	024-19082-031	1	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3	3
15KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,10.0KW480V,6ELEM	025-26318-005	1	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3	3
20KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,21.2KW,600	025-26318-006	1	1	1	1
CONTACTOR,ELEC,	024-24100-700	1	1	1	1
CONTACTOR,ELEC,	024-24101-700	2	2	2	2
RELAY,CONT 24V50/60HZSPST	024-24103-000	1	1	1	1
CONTROL,TEMPERATURE	025-26339-002	1	1	1	1
30KW					
		3 Ton	4 Ton	5 Ton	6 Ton
HEATER,ELEC,30.4KW,600	025-26318-011	-	-	1	1
CONTACTOR,ELEC,	024-24100-700	-	-	1	1
CONTACTOR,ELEC,	024-24101-700	-	-	2	2
RELAY,CONT 24V50/60HZSPST	024-24103-000	-	-	1	1
CONTROL,TEMPERATURE	025-26339-001	-	-	1	1
CONVENIENCE OUTLET					
No Convenience Outlet					
Direct Drive		3 Ton	4 Ton	5 Ton	6 Ton
PANEL,CORNER	373-26214-001	1	1	1	1
Belt Drive		3 Ton	4 Ton	5 Ton	6 Ton
PANEL,CORNER	373-12429-003	1	1	1	1
Non Powered Convenience Outlet, Standard Cabinet					
Standard Cabinet					
Direct Drive		3 Ton	4 Ton	5 Ton	6 Ton
OUTLET,CONVENIENCE	025-31987-000	1	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1	1
PANEL,CORNER,DIRECT DRIVE,	373-26214-002	1	1	1	1
Belt Drive		3 Ton	4 Ton	5 Ton	6 Ton
OUTLET,CONVENIENCE	025-31987-000	1	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1	1
PANEL,CORNER,FRONT,BELT DRIVE	373-12429-003	1	1	1	1
Tool-less Cabinet					
Direct Drive		3 Ton	4 Ton	5 Ton	6 Ton

PANEL,CORNER	373-26214-004	1	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1	1
OUTLET,CONVENIENCE	025-31987-000	1	1	1	1
Belt Drive					
		3 Ton	4 Ton	5 Ton	6 Ton
PANEL,CORNER,FRONT	373-12429-004	1	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1	1
OUTLET,CONVENIENCE	025-31987-000	1	1	1	1
Powered Convenience Outlet Direct Drive					
208/230 VOLT (1 & 3 Phase)					
		3 Ton	4 Ton	5 Ton	6 Ton
OUTLET,CONVENIENCE	025-31987-000	1	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000	1	1	1	1
TRANSFORMER,208/230-120	025-32672-240	1	1	1	1
FUSE,600V,30A	025-32733-001	2	2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000	2	2	2	2
COVER,SWITCH	025-31977-000	1	1	1	1
PANEL,CORNER,FRONT,DD,STD CABINET	373-26214-002	1	1	1	1
PANEL,CORNER,FRONT,DD,TOOLLESS	373-26214-004	1	1	1	1
460 VOLT					
		3 Ton	4 Ton	5 Ton	6 Ton
OUTLET,CONVENIENCE	025-31987-000	1	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000	1	1	1	1
TRANSFORMER,3KVA,240/480	025-32762-000	1	1	1	1
FUSE,600V,30A	025-32733-001	2	2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000	2	2	2	2
COVER,SWITCH	025-31977-000	1	1	1	1
PANEL,CORNER,FRONT,DD,STD CABINET	373-26214-002	1	1	1	1
PANEL,CORNER,FRONT,DD,TOOLLESS	373-26214-004	1	1	1	1
575 VOLT					
		3 Ton	4 Ton	5 Ton	6 Ton
OUTLET,CONVENIENCE	025-31987-000	1	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000	1	1	1	1
TRANSFORMER,3KVA,600	025-30383-000	1	1	1	1
FUSE,600V,30A	025-32733-001	2	2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000	2	2	2	2
COVER,SWITCH	025-31977-000	1	1	1	1
PANEL,CORNER,FRONT,DD,STD CABINET	373-26214-002	1	1	1	1
PANEL,CORNER,FRONT,DD,TOOLLESS	373-26114-004	1	1	1	1
Belt Drive					
208/230 VOLT (1 & 3 Phase)					
		3 Ton	4 Ton	5 Ton	6 Ton
OUTLET,CONVENIENCE	025-31987-000	1	1	1	1

Source 1 Products

035-19409-002-A-0603
Supercedes: Nothing

New Replacement Parts shown in **bold** face at the first printing of the parts list date coded 0303

SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000	1	1	1	1
TRANSFORMER,208/230-120V	025-32672-240	1	1	1	1
FUSE,600V,30A	025-32733-001	2	2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000	2	2	2	2
COVER,SWITCH	025-31977-000	1	1	1	1
PANEL,CORNER,FRONT,BD,STD CABINET	373-12429-003	1	1	1	1
PANEL,CORNER,FRONT,BD,TOOLLESS	373-12429-004	1	1	1	1
460 VOLT					
		3 Ton	4 Ton	5 Ton	6 Ton
OUTLET,CONVENIENCE	025-31987-000	1	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000	1	1	1	1
TRANSFORMER,3KVA,240/480	025-32762-000	1	1	1	1
FUSE,600V,30A	025-32733-001	2	2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000	2	2	2	2
COVER,SWITCH	025-31977-000	1	1	1	1
PANEL,CORNER,FRONT,BD,STD CABINET	373-12429-003	1	1	1	1
PANEL,CORNER,FRONT,BD,TOOLLESS	373-12429-004	1	1	1	1
575 VOLT					
		3 Ton	4 Ton	5 Ton	6 Ton
OUTLET,CONVENIENCE	025-31987-000	1	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000	1	1	1	1
TRANSFORMER,3KVA,600PRI	025-30383-000	1	1	1	1
FUSE,600V,30A	025-32733-001	2	2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000	2	2	2	2
COVER,SWITCH	025-31977-000	1	1	1	1
PANEL,CORNER,FRONT,BD,STD CABINET	373-12429-003	1	1	1	1
PANEL,CORNER,FRONT,BD,TOOLLESS	373-12429-004	1	1	1	1
DISCONNECT					
No Disconnect Option		3 Ton	4 Ton	5 Ton	6 Ton
COVER,CONTROL BOX	373-02023-000	1	1	1	1
Disconnect Option					
208/230-1-60		3 Ton	4 Ton	5 Ton	6 Ton
SWITCH,DISCONNNECT,150A,600V	024-24493-200	1	1	1	-
BRACKET,SWITCH MOUNT	073-16465-000	1	1	1	-
COVER,CONTROL BOX	373-16466-000	1	1	1	-
Disconnect Option					
208/230-3-60, 460-3-60, 575-3-60		3 Ton	4 Ton	5 Ton	6 Ton
SWITCH,DISCONNNECT,150A,600V	024-27548-000	1	1	1	1
BRACKET,SWITCH MOUNT	073-16465-000	1	1	1	1

COVER,CONTROL BOX	373-16466-000	1	1	1	1
MOTORIZED DAMPER					
DAMPER,AIR	373-21440-000	1	1	1	1
ACTUATOR,24SPLYV,25TRQ	025-26351-700	1	1	1	1
BALL JOINT	029-08786-000	1	1	1	1
PLATE,DIVIDER	073-21441-000	1	1	1	1
PANEL,SIDE,RH	063-89623-700	1	1	1	1
PANEL,SIDE,LH	063-89624-700	1	1	1	1
COVER,TOP,FILTER	063-89630-700	1	1	1	1
COVER,TOP,FRESH AIR HOOD	063-89631-700	1	1	1	1
ANGLE,BOTTOM,FRESH AIR HOOD	063-89632-070	1	1	1	1
FILTER,AIR,CLEANABLE	026-25514-000	2	2	2	2
ECONOMIZER					
No Economizer		3 Ton	4 Ton	5 Ton	6 Ton
HARNES, JUMPER	363-89845-604	1	1	1	1
With Economizer					
Single Enthalpy		3 Ton	4 Ton	5 Ton	6 Ton
CONTROL,LOGIC	031-01965-000	1	1	1	1
CONTROL,ENTHALPY	031-00863-000	1	1	1	1
ACTUATOR,24V	025-38231-000	1	1	1	1
TEMPERATURE SENSOR	031-00878-001	1	1	1	1
SEAL,SIDE,AIR DAMPER	029-18444-000	1	1	1	1
SEAL,DAMPER BLADE	029-18443-000	1	1	1	1
SEAL,DAMPER BLADE	029-18442-000	1	1	1	1
CONNECTOR,1/4"	029-18438-000	1	1	1	1
BRACKET,DAMPER	029-18440-000	3	3	3	3
PIVOT,BRASS W/SET SCREW	029-18439-000	7	7	7	7
JOINT,BALL	029-08786-000	1	1	1	1
PANEL,SIDE,R.H.,FRESH AIR HOOD	063-89623-000	1	1	1	1
PANEL,SIDE,L.H.,FRESH AIR HOOD	063-89624-000	1	1	1	1
COVER,TOP,FRESH AIR HOOD	063-89631-000	1	1	1	1
COVER,TOP,FILTER	063-89630-700	1	1	1	1
ANGLE,BOTTOM,FRESH AIR	063-89632-700	1	1	1	1
FILTER,AIR,CLEANABLE	026-25514-000	2	2	2	2
MOTORIZED DAMPER					
ACTUATOR,24SPLYV,25TRQ	025-26351-700	1	1	1	1
BALL JOINT	029-08786-000	1	1	1	1
DAMPER,AIR	373-21440-000	1	1	1	1

PLATE,DIVIDER	073-21441-000	1	1	1	1
PANEL,SIDE,RH	063-89623-700	1	1	1	1
PANEL,SIDE,LH	063-89624-700	1	1	1	1
COVER,TOP,FILTER	063-89630-700	1	1	1	1
COVER,TOP,FRESH AIR HOOD	063-89631-700	1	1	1	1
ANGLE,BOTTOM,FRESH AIR HOOD	063-89632-070	1	1	1	1
FILTER,AIR,CLEANABLE	026-25514-000	2	2	2	2
SMOKE DETECTOR					
Return Air No Smoke Detector					
		3 Ton	4 Ton	5 Ton	6 Ton
HARNES,JUMPER	025-35366-009	1	1	1	1
Smoke Detector					
		3 Ton	4 Ton	5 Ton	6 Ton
SMOKE DETECTOR	029-22291-000	1	1	1	1
Supply Air No Smoke Detector					
		3 Ton	4 Ton	5 Ton	6 Ton
HARNES,JUMPER	025-35366-009	1	1	1	1
Smoke Detector					
		3 Ton	4 Ton	5 Ton	6 Ton
SMOKE DETECTOR	029-22291-000	1	1	1	1
COIL GUARD					
		3 Ton	4 Ton	5 Ton	6 Ton
COIL GUARD	026-25570-017	1	1	1	1
PHASE MONITOR					
		3 Ton	4 Ton	5 Ton	6 Ton
PHASE MONITOR,0-600V	031-01922-000	1	1	1	1
BAS READY COMPONENTS					
		230V	460V	575V	
CIRCUIT BREAKER,3.2A,250V	024-31976-000	1	1	1	
TRANSFORMER,.075KVA,208/230-24	025-25973-700	1	-	-	
TRANSFORMER,.075KVA,460	025-25974-700	-	1	-	
TRANSFORMER,75KVA	025-27732-700	-	-	-	
TRANSFORMER,575V/24V/75A	025-27729-700	-	-	1	
TERMINAL BLOCK,2P,250V,20A	025-30887-000	1	1	1	

BAS CPC

		230V	460V	575V
CONTROL,CPC	031-01940-000	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
SWITCH, PRESSURE TAP	023-16881-000	1	1	1
SWITCH,PRESSURE DIFF	024-32007-000	2	2	2
RELAY SS DC CONTROL	024-32008-000	1	1	1
TRANSFORMER, .075KVA 208/230-24	025-25973-700	1	-	-
TRANSFORMER, .075 KVA 460PRI-24	025-25974-700	-	1	-
TRANSFORMER, 575V/24V 75A	025-27729-700	-	-	1
CAPACITOR,100UF 50WVDC	031-01956-000	1	1	1
SENSOR,TEMP,CPC	031-01945-000	2	2	2
BRACKET,SENSOR	063-87678-000	1	1	1

BAS NOVAR

		230V	460V	575V
CONTROL,NOVAR	031-01939-000	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
SWITCH, PRESSURE TAP	023-16881-000	1	1	1
SWITCH,PRESSURE DIFF	024-32007-000	2	2	2
RELAY SS DC CONTROL	024-32008-000	1	1	1
TRANSFORMER, .075KVA 208/230-24	025-25973-700	1	-	-
TRANSFORMER, .075 KVA 460PRI-24	025-25974-700	-	1	-
TRANSFORMER, 575V/24V 75A	025-27729-700	-	-	1
CAPACITOR,100UF 50WVDC	031-01956-000	1	1	1
SENSOR,TEMP,NOVAR	031-01944-000	2	2	2

**BAS JOHNSON CONTROL
NO ECONOMIZER**

		230V	460V	575V
CONTROL,JOHNSON UNIT	031-01937-000	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
SWITCH, PRESSURE TAP	023-16881-000	1	1	1
SWITCH,PRESSURE DIFF	024-32007-000	2	2	2
RELAY SS AC CONTROL	024-32027-000	1	1	1
TRANSFORMER .075KVA 208/230-24	025-25973-700	1	-	-
TRANSFORMER .075 KVA 460PRI-24	025-25974-700	-	1	-
TRANSFORMER, 575V/24V 75A	025-27729-700	-	-	1
CAPACITOR,100UF 50WVDC	031-01956-000	1	1	1
SENSOR,TEMP,JCI	031-01946-000	2	2	2
BRACKET,SENSOR	063-87678-000	1	1	1

WITH ECONOMIZER

		230V	460V	575V

Source 1 Products

035-19409-002-A-0603
Supercedes: Nothing

New Replacement Parts shown in **bold** face at the first printing of the parts list date coded 0303

CONTROL,JOHNSON UNIT	031-01937-000	1	1	1	
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1	
SWITCH, PRESSURE TAP	023-16881-000	1	1	1	
SWITCH,PRESSURE DIFF	024-32007-000	2	2	2	
RELAY SS AC CONTROL	024-32027-000	1	1	1	
TRANSFORMER .075KVA 208/230-24	025-25973-700	1	-	-	
TRANSFORMER .075 KVA 460PRI-24	025-25974-700	-	1	-	
TRANSFORMER, 575V/24V 75A	025-27729-700	-	-	1	
CAPACITOR,100UF 50WVDC	031-01956-000	1	1	1	
SENSOR,TEMP,JCI	031-01946-000	2	2	2	
SENSOR	031-01120-000	1	1	1	
BRACKET,SENSOR	063-87678-000	1	1	1	
BAS HONEYWELL CONTROL NO ECONOMIZER					
		230V	460V	575V	
CONTROL,HONEYWELL	031-01938-000	1	1	1	
CONTROL,ISOLATION RELAY	031-01941-000	1	1	1	
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1	
SWITCH, PRESSURE TAP	023-16881-000	1	1	1	
SWITCH,PRESSURE DIFF	024-32007-000	2	2	2	
RELAY SS DC CONTROL	024-32008-000	1	1	1	
TRANSFORMER,.075KVA208/230-24	025-25973-700	1	-	-	
TRANSFORMER,.075KVA,460PRI-24	025-25974-000	-	1	-	
TRANSFORMER,575V/24V,75A	025-27729-000	-	-	1	
CAPACTOR,100UF 50WVDC	031-01956-000	1	1	1	
SENSOR,TEMPERATURE,20K OHM	031-01943-000	2	2	2	
WITH ECONOMIZER					
		230V	460V	575V	
CONTROL,HONEYWELL	031-01938-000	1	1	1	
CONTROL,ENTHALPY	031-00863-000	1	1	1	
CONTROL,ISOLATION RELAY	031-01941-000	1	1	1	
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1	
SWITCH, PRESSURE TAP	023-16881-000	1	1	1	
SWITCH,PRESSURE DIFF	024-32007-000	2	2	2	
RELAY SS DC CONTROL	024-32008-000	1	1	1	
TRANSFORMER .075KVA 208/230-24	025-25973-700	1	-	-	
TRANSFORMER .075 KVA 460PRI-24	025-25974-700	-	1	-	
TRANSFORMER, 575V/24V 75A	025-27729-700	-	-	1	
SENSOR,TEMP 20K OHM	031-01943-000	2	2	2	
CAPACITOR,100UF 50WVDC	031-01956-000	1	1	1	
RESISTOR,500 OHM	031-01942-000	1	1	1	