

Simplicity® Equipment and Controls Matrix

	Simplicity 1	Simplicity Intelli-Comfort	Simplicity Elite	Simplicity Wireless	Simplicity BRIDGE	Synthesys	JCI - 1126	Honeywell W7750	CPC	Novar ETC3
3 - 6 ton Sunline	S	O	N/A	O	O	N/A	O	O	O	O
6.5 - 12.5 ton Predator	S	O	N/A	O	O	N/A	O	O	O	O
15 - 25 ton Sunline	S	O	N/A	O	O	N/A	O	O	O	O
25 - 40 ton Millennium RTU	N/A	N/A	S	N/A	O	O	N/A	N/A	N/A	N/A
15 - 50 ton Millennium Splits	S	N/A	N/A	O	O	N/A	N/A	N/A	N/A	N/A
S = Standard, O = Optional, N/A = Not Applicable										


The Simplicity Wireless only operates with Simplicity 1

Simplicity Intelli-Comfort is a complete Space Comfort Controller

Simplicity Elite is a complete Space Comfort Controller

Simplicity Wireless is for one way remote Alarming

Simplicity BRIDGE is used for two way remote Alarming



Any other BAS or EMS control will wire into the standard Simplicity® Elite™ via the thermostat terminals on the board.

Simplicity® is compatible with all BAS or EMS controls.

Figure 1