

ACCESSORY KIT INSTALLATION MANUAL

RUBBER COIL MOUNT KIT S1-3281550000 FOR USE WITH MODELS: TCGD & GCGD

GENERAL INFORMATION

Rubber coil mount acts as a spacer between top and coil.

IMPORTANT - Failure to use rubber coil mount could result in coil damage.

INSTALLATION

1. Remove all screws securing top assembly to coil guard and control box cover.
2. Lift and rotate top assembly approximately 1/8 turn to rest on top of coil.
3. Insert coil spacer between coil guard rods immediately next to the coil guard coined rod so that spacer is in straight portion of coil guard. Refer to Figures 1 & 2.
4. Repeat steps for all 4 locations around coil. Refer to Figure 3.
5. Reorient top on unit starting with coil guard opposite control box, finishing with control box corner of the unit. Secure top with screws.

NOTE: Units with microchannel tube damage must be leak tested and unit not used if leak is detected or damage to tube is severe.



FIGURE 1



FIGURE 2



FIGURE 3